

INFILTRATION BASIN: Operation and Maintenance

- Check accessibility to basin area, riser and outlet.
- Check for woody vegetation on embankment within 25' of the riser.
- Check for displacement of riprap and erosion below outlet.
- Debris and litter shall be removed during regular mowing operations.
- Check basin area for dewatering within 48 hours of rainfall. Check for noticeable odors, water stains on the filter surface or at the outlet; presence of algae or aquatic vegetation.
- When dewatering fails within 48 hours, remove the top 3 to 6 inches of soil/sediment and replace with suitable material per plan. Follow up inspections shall confirm adequate dewatering.

